

OIL PUMP ACCESSORIES

PUMP BRACKETS



PM2 AND PM4 PUMP BRACKETS

360 102 Wall bracket

360 120 Floor bracket

360 106 Bracket for fixing a pump and a hose reel on top of a 1.000 I IBC

Requires pump bracket 360 102 (not included).

360 107 Bracket for fixing a pump and a hose reel laterally on a 1.000 I IBC

Requires pump bracket 360 102 (not included).

360 108 Bracket for fixing a pump laterally on a 1.000 I IBC

Requires pump bracket 360 102 (not included).

PM35 PUMP BRACKETS

360 139 Wall bracket, bung mount pump (2" F).

360 140 Wall bracket, flange mount pump (4 x M8).

PM45 AND PM60 PUMP BRACKETS

360 132 Wall bracket

360 121 Floor bracket

CONNECTION ADAPTERS AND VALVES



CONNECTION ADAPTERS

945 590, 1/4" BSP (MM).

945 592, 3/8" BSP (MM).

945 558, 1/2" BSP (MM).

945 551, 3/4" BSP (MM).

945 555, 1" BSP (MM).

945 724, 1 1/2" BSP (MM).

945 681, 1 1/2" BSP (M) - 1" BSP (M).

945 552 1" BSP (M) - 3/4" BSP (M).

945 554, 3/4" BSP (M) - 1/2" BSP (M).

945 557, 1/2" BSP (M) - 3/8" BSP (M).

945 567, 2" BSP (M) - 1 1/2" BSP (M).

945 565, 2" BSP (M) - 1" BSP (F).

945 513, 1 1/4" BSP (M) - 3/4" BSP (F).

945 670, 1" BSP (M) - 3/4" BSP (F).

369 900, 3/4" BSP (M) - 1/2" BSP (F).

945 556, 1/2" BSP (M) - 3/8" BSP (F).

369 601, 1/2" BSP (MM) 45° elbow.

945 572, 3/4" BSP (MF) 90° elbow.

945 548, 1/2" BSP (MM) 90° elbow.

945 738, 3/4" BSP (M) - 3/4" BSP (F) elbow.

LOW AND MEDIUM PRESSURE VALVES

950 305, 1/4" BSP (FF), 65 bar quarter turn valve.

950 320, 3/8" BSP (FF), 65 bar quarter turn valve.

950 300, 1/2" BSP (FF), 65 bar quarter turn valve.

950 303, 3/4" BSP (FF), 40 bar quarter turn valve.

950 306, 1" BSP (FF), 40 bar quarter turn valve.

950 312, 1-1/2" BSP (FF), 25 bar quarter turn valve.

950 308, 2" BSP (FF), 25 bar quarter turn valve.

HIGH PRESSURE VALVES

950 304, 1/2" BSP (FF), 500 bar quarter turn valve.

950 328, 3/4" BSP (FF), 400 bar quarter turn valve.

950 329, 1" BSP (FF), 350 bar quarter turn valve.

AIR LINE SHUTOFF VALVES

950 302, Needle air valve 1/4" BSP (FF).

950 321, Air valve 1/4" BSP (FF).

950 318, Air valve 3/8" BSP (FF).

950 319, Air valve 1/2" BSP (FF).

362 104

OIL HOSES



Manufactured in NBR with a steel reinforcement braid. With two swaged nuts and male-male adaptors on both ends.

362 100, 1 m x 1/2". Working pressure: 160 bar. Connection threads: 1/2" BSP (MM).

362 101, 1,5 m x 1/2". Working pressure: 160 bar. Connection threads: 1/2" BSP (MM).

362 102, 2 m x 1/2". Working pressure: 160 bar. Connection threads: 1/2" BSP (MM).

362 103, 3 m x 1/2". Working pressure: 160 bar. Connection threads: 1/2" BSP (MM).

362 104, 4 m x 1/2". Working pressure: 160 bar. Connection threads: 1/2" BSP (MM).

362 300, 1 m x 3/4". Working pressure: 100 bar. Connection threads: 3/4" BSP (MM).

362 301, 1,5 m x 3/4". Working pressure: 100 bar. Connection threads: 3/4" BSP (MM).

362 302, 1,8 m x 3/4". Working pressure: 100 bar. Connection threads: 3/4" BSP (MM).

362 303, 3 m x 3/4". Working pressure: 100 bar. Connection threads: 3/4" BSP (MM).