

DIAPHRAGM PUMP ACCESSORIES

DIAPHRAGM PUMP AIR CONNECTION KITS



362 920

AIR BLEEDING VALVES



362 922

Air connection kits include an air pressure regulator for adjusting pump speed.

PART No.	362 920	362 921	362 928
APPLICATION	DF30, DF50, DF100	DP200	DF250
AIR QUICK COUPLER	1/4" BSP (F) 253 114	3/8" BSP (F) 253 138	3/8" BSP (F) 253 138
AIR QUICK NIPPLE	3/8" BSP (M) 259 038	3/8" BSP (M) 259 038	1/2" BSP (M) 259 012
AIR HOSE	1 m x 1/4" 246 010	1 m x 3/8" 247 710	1 m x 3/8" 247 710
AIR PRESSURE REGULATOR	1/4" BSP (FF) 240 200	1/2" BSP (FF) 240 201	1/2" BSP (FF) 240 201
CONNECTION ADAPTOR	1/4" x 3/8" BSP (MM) 239 001	1/2" x 3/8" BSP (MM) 239 003	1/2" x 3/8" BSP (MM) 239 003
AIR VALVE	3/8" BSP (FF) 950 318	3/8" BSP (FF) 950 318	3/8" BSP (FF) 950 318

When connected to the pump outlet, it helps to eliminate the air trapped in the pump and in the suction line aiding pump prime.

362 922, 1/2" Air bleeding valve. For DF30 and DF50 diaphragm pumps.

362 923, 3/4" Air bleeding valve. For DF100 diaphragm pumps.

362 924, 1" Air bleeding valve. For DF250 and DP200 diaphragm pumps.

03
OTHER FLUIDS
PUMPS

PUMP INSTALLATION EXAMPLES

- 1 AIR CONNECTION KIT
- 2 SUCTION KIT
- 3 PUMP WALL BRACKET
- 4 AIR BLEEDING VALVE
- 5 PRESSURE RELEASE VALVE

