# **WASTE OIL EQUIPMENT ACCESSORIES**

## HYDRAULIC CONNECTORS

## SHUT OFF VALVES

## **CONNECTION ADAPTORS**





Dry-Brake hydraulic couplers and connectors. **950 352**, 3/4" BSP (F) hydraulic connectors. **950 353**, 3/4" BSP (F) hydraulic coupler.

**950 354,** 1" BSP (F) hydraulic connectors. **950 355,** 1" BSP (F) hydraulic coupler.

**950 356,** 1-1/2" BSP (F) hydraulic connectors. **950 357,** 1-1/2" BSP (F) hydraulic coupler.



**950 303,** 3/4" BSP (FF), 40 bar quarter turn valve

**950 306,** 1" BSP (FF), 40 bar quarter turn valve **950 312,** 1-1/2" BSP (FF), 25 bar quarter

**950 308,** 2" BSP (FF), 25 bar quarter turn valve







945 551, 3/4" BSP (MM) 945 555, 1" BSP (MM) 945 724, 1 1/2" BSP (MM) 945 681, 1 1/2" BSP (M) - 1" BSP (M) 945 552, 1" BSP (M) - 3/4" BSP (M) 945 554, 3/4" BSP (M) - 1/2" BSP (M) 945 557, 1/2" BSP (M) - 3/8" BSP (M)

**945 567**, 2" BSP (M) - 1 1/2" BSP (M) **945 565**, 2" BSP (M) - 1" BSP (F)



## SUCTION CANES AND ADAPTORS

#### 737 950 Suction canes and adaptors set

Includes canes Part No. 739 949, 737952, 737 953, 737 954, 737 955 and adapters Part No. 737 947 and 737 948.

#### 737 972 Suction canes and adaptors set with canes holder

Canes and adaptors set Part No. 737 950 with a suction canes holder.

INDIVIDUAL WANDS AND ADAPTORS		
PART No.	ТҮРЕ	DESCRIPTION OD X ID X LENGTH
737 952	Flex	6 x 4 x 700 mm
737 953	Flex	8 x 6 x 700 mm
737 954	Rigid Copper	5 x 4 x 700 mm
737 955	Rigid Copper	6 x 5 x 700 mm
737 949	Flex	7 x 5 x 1,000 mm
737 958	Flex	6 x 4 x 1,200 mm
737 959	Flex	8 x 6 x 1,200 mm
737 946	Flex	8 x 6 x 1,700 mm