

The meter element can be added with various accessories to obtain view the following configuration:

	NO STRAINER NO AIR ELIMINATOR NO VALVE	STRAINER NO AIR ELIMINATOR NO VALVE	STRAINER AIR ELIMINATOR NO VALVE	STRAINER AIR ELIMINATOR NO VALVE AIR-CHECK	NO STRAINER NO AIR ELIMINATOR VALVE	STRAINER NO AIR ELIMINATOR VALVE	STRAINER AIR ELIMINATOR VALVE	STRAINER AIR ELIMINATOR VALVE AIR-CHECK
COUNTER NO PRINTER NO PRE-SET	<b>A</b> 	<b>B</b> 	<b>C</b> 	<b>CX</b> 			<b>D</b> 	<b>DX</b> 
COUNTER PRINTER NO PRE-SET	<b>E</b> 	<b>F</b> 	<b>G</b> 	<b>GX</b> 			<b>H</b> 	<b>HX</b> 
COUNTER NO PRINTER PRE-SET					<b>I</b> 	<b>J</b> 	<b>K</b> 	<b>KX</b> 
COUNTER PRINTER PRE-SET					<b>L</b> 	<b>M</b> 	<b>N</b> 	<b>NX</b> 
NO COUNTER NO PRINTER NO PRE-SET	<b>P</b> 	<b>R</b> 	<b>S</b> 	<b>SX</b> 	<b>U</b> 	<b>V</b> 	<b>T</b> 	<b>TX</b> 

